



## INSTALLATION & USER GUIDE



# ParWire<sup>®</sup> GLIDE BASKET



**CAUTION**

Read and understand all of the instructions and safety information in this document before operating this product.

## WARNING

### INSTALLATION

- Not for use in mobile applications.
- A Standard Wire or Solid Shelf or 4-Sided Frame must be located at the bottom and middle of the unit. The top of the unit may be equipped with one of those or a ParWire® Fixed/Stationary Basket.
- Shelving unit must be anchored to the floor or wall, or to another similar sized shelving unit in a back:back orientation.
- LogiQuip can provide Anchoring Kits for the floor and wall.
- A unit with one (1) Gliding Basket does not need to be secured, and configurations with more Gliders do get secured. Single Baskets can be used anywhere in the unit, subject to a fixed component being in the top, bottom, and middle.

### USE

- Standard and Fine Mesh Dividers are available in front:back and side:side configurations.
- Do not load more than 50 lbs. in a Glide Basket.
- Do not pull out more than one Basket at a time.
- When pulling-out the Glide Basket, grab it at the middle; do not pull it out from the side.
- Do not use the Glide Basket as a step.

**SAVE THESE INSTRUCTIONS**

Any of the accessories for Fine Mesh Baskets can be used with this product.

Healthcare exclusive since 1992, LogiQuip's Inventory Management Solutions are designed for Healthcare Professionals looking for a better way to manage supply chain tasks. With Expert Advice, Innovative Solutions, and 360 Service that doesn't stop after the sale, LogiQuip's sole purpose is to ensure Healthcare Professionals have the supplies they need when they need them. Partnering with you to design and implement the right solutions, we give you time back to focus on what's important; Patient Care.