

Intelli-Flip[®] INVENTORY SYSTEM

SUPPLY AVAILABILITY MADE EASY!

FOLLOW THESE SIMPLE STEPS TO MAINTAIN PROPER STOCK LEVELS FOR ALL YOUR SUPPLIES!

Intelli-Flip replaces the traditional plastic two-bin system and automates supply tracking. A monitor attached to the Flipper placed in the center of the bin signals that PAR levels are low when it is pulled down to access supplies behind the Flipper.

1 FULLY STOCKED SHELVES

When shelves are fully stocked, all of the Flippers are in the **UP** position.



2 GET SUPPLIES

Easily obtain the supplies you need when you need them.



3 PULL DOWN THE FLIPPER WITH INTELLI-FLIP

Once supplies are gone in front of the Flipper simply pull it down and an order will be sent to the appropriate stocking location.



4 CONTINUE TO GET SUPPLIES

Continue to use supplies from behind the Flipper until the bin is restocked.

