



LOGICELL WIDE SHELF-(CAT.#2436SHC-3)

- LogiCell Two Column Shelf with Catheter Slide Mounts
- Accommodates up to 31 Dividers
- Accommodates up to 8 Catheters
- 35-LB. WT. Capacity
- Occupies 2 Cells

SKU: 2436SHC-3

Categories: [logicell-accessories](#)

PRODUCT DESCRIPTION

LogiCell Metal Shelves are used to store larger or bulky items in the LogiCell units . The shelf has a 2 .5" H lip on the rear to prevent items from sliding back . The front slopes down 1" H to provide a labeling surface . The Metal Shelf can also be inserted in the reverse direction to retain items on the shelf in a slanted position . There are slots every 1" for attaching the Metal Divider to the Shelf, and an added channel across the rear and front that accepts Catheter Slides .



ADDITIONAL INFORMATION

Dimensions	24 × 36 × 2.5 in
Product Line	LogiCell
Product Category	logicell-accessories