



# Scrub SINKS



# LOGIQUIP® SCRUB SINKS

**Scrub Sinks** are essential to any OR and help to ensure patient safety. LogiQuip's entire line of **Stainless Steel Scrub Sinks** are hands-free scrub stations that are **Knee** and/or **Infrared** operated to minimize cross-contamination. With standard features such as **Deep Sloping Basins, Adjustable Thermostatic Controlled Pressure Regulating Mixing Valve** and **Flow Control Valves**, and optional features such as **Foot Operated Water and Soap, Digital Scrub Timer**, and **Eye Wash**, our **Scrub Sinks** can be built out to specification.

## KNEE OPERATED SCRUB SINKS

The operation of these **Scrub Sinks** is simple. Press the **Knee Panel** one time to activate water flow. Press again to stop the flow. The **Soap Panel** works in a pumping fashion with soap being dispensed through a **Stainless Steel Spout** located near the **Mixing Valve**. The **Sink Base** has been designed to accommodate a gallon-sized soap container storage behind the **Knee Panels**.

## 304 STAINLESS STEEL\*

LogiQuip **Scrub Sinks** are **304 Stainless Steel** making them durable, easy-to-clean, and corrosion-resistant.

\*See the LogiQuip Cleaning Guide for cleaning instructions.

## OPTIONAL ACCESSORIES

Several additional options such as **Foot Operated Water and Soap, Eye Wash, Digital Scrub Timer**, and **In-Wall Chair Carrier** are available to customize your **Scrub Sink** to your specific needs.

## INFRARED OPERATED SCRUB SINKS

The **Infrared Sensor** is located on the front of each station and is activated by the user standing in front of the **Scrub Sink**. There is a 2-second on/off delay for water flow. The **Sensor Range** is 12"-14". Both features combined eliminate activation by simply passing by. **Optional Knee Operated or Foot Control Soap Pumps** are available.

## LIMITED 5-YEAR WARRANTY

LogiQuip products are covered by a **Limited 5-Year Warranty** from date of receipt against defect in materials or workmanship under normal use and service, excluding **Electronic Components, Cart Covers, Custom Products, LogiCell Tambour Doors, Label Holders, and Casters**. During this period, LogiQuip will, in its sole discretion, repair defects in materials or workmanship that existed when the product was received or replace the product. Visit [LogiQuip.com/Warranty](https://LogiQuip.com/Warranty) for more details.



MODEL # SS69

# STANDARD FEATURES & OPTIONS

## STANDARD FEATURES

- 1 Knee Operation Water & Soap
- 2 IR Water Dispenser
- 3 24 Volt Plug In Transformer
- 4 304 Stainless Steel Construction
- 5 Adjustable Thermostatic Controlled Pressure Mixing Valve†
- 6 Deep Sloping Basins with Splash Divider
- 7 Check Stop Strainers
- 8 Swivel, High Mount Gooseneck Spout with Adjustable Swivel Spray Aerator
- 9 Backflow Preventers

\* 1-Station Scrub Sinks have one (1) sink; 2-Station Scrub Sinks have two (2) sinks; 3-Station Scrub Sinks have three (3) sinks

† One (1) Per Sink



## OPTIONAL FEATURES

- Infrared Operation
- Infrared Soap Dispenser
- Eye Wash
- Thermostatic Mixing Valve (Add-On To Eye Wash Option)
- Manual Bypass To Add Knee Operated Water & Soap With IR Operation
- Knee Operated Soap With IR Water Operation
- Foot Operated Water
- Foot Operated Soap
- Digital Scrub Timer
- Laminar Flow
- 220/240v Power Supply
- Pedestal Base
- In-Wall Chair Carrier
- Wall Shelf Over Sink
- Lighted Wall Shelf Over Sink

# KNEE OPERATED SCRUB SINKS

## KNEE OPERATED SCRUB SINKS

**Scrub Sinks** are essential to any OR and help to ensure patient safety. Turn water on and off and dispense soap with the simple press of a knee panel. Available in **1-Station**, **2-Station**, and **3-Station**, these hands-free **Scrub Sinks** come standard with **Knee Operated Soap Dispenser**, **Adjustable Thermostatic Controlled Pressure Regulating Mixing Valve**, **Check Stop Strainers**, **Flow Control Valve**, and more.

KNEE OPERATED SCRUB SINKS – FEATURES & MODELS			
FEATURES	SS32 1-Station 27.5" x 32" x 37"	SS64 2-Station 27.5" x 64" x 37"	SS96 3-Station 27.5" x 96" x 37"
Number of Stations	1	2	3
Adjustable Thermostatic Controlled Pressure Regulating Mixing Valve	1	2	3
Knee Operated Water & Soap	•	•	•
Check Stop Strainers	•	•	•
Swivel, High Mount Gooseneck Spout with Spray Aerator (1/station)	1	2	3
Flow Control Valve	•	•	•
Backflow Preventers	•	•	•
Splash Screen Dividers	0	1	2



MODEL # SS32



MODEL # SS64

# INFRARED (IR) OPERATED SCRUB SINKS

## IR OPERATED SCRUB SINKS

**Scrub Sinks** are essential to any OR and help to ensure patient safety. Turn on the water by simply standing in front of the **Scrub Sink** with our **Infrared Sensor Scrub Sinks**. Located on the front of each station, merely walk up to station and start washing. Available in **1-Station**, **2-Station**, and **3-Station**, our **Infrared Water Operated Scrub Sinks** come standard with a **Hand Operated Soap Dispenser**, **Adjustable Thermostatic Controlled Pressure Regulating Mixing Valve**, **Check Stop Strainers**, **Flow Control Valve**, and more. Add our optional **Infrared Soap Dispenser** for a truly hands-free **Scrub Sink**.

IR OPERATED SCRUB SINKS – FEATURES & MODELS			
FEATURES	SS32-IR 1-Station 27.5" x 32" x 37"	SS64-IR 2-Station 27.5" x 64" x 37"	SS96-IR 3-Station 27.5" x 96" x 37"
Number of Stations	1	2	3
Adjustable Thermostatic Controlled Pressure Regulating Mixing Valve	1	2	3
IR Operated Water	•	•	•
Check Stop Strainers	•	•	•
Swivel, High Mount Gooseneck Spout with Spray Aerator (1/station)	1	2	3
Flow Control Valve	•	•	•
Backflow Preventers	•	•	•
Splash Screen Dividers	0	1	2



MODEL # SS32-IR-IRD  
Shown With Optional  
Infrared Soap Dispenser



MODEL # SS96-IR





[www.logiquip.com](http://www.logiquip.com)

(800) 665-3760 | [customersupport@logiquip.net](mailto:customersupport@logiquip.net)

10.2021